



PART #	DESCRIPTION	• Fittings made for automatic ballast systems
W730	Female Quick Connect sac threads with Male Quick Connect Cap and Chain	
W731	Wally Plug	
W732	Female GHT with Male Quick Connect (for use with garden hose)	
W733	• 1" Barbed End sac threads (for integrating multiple sacs)	
W734	Male Quick Connect with Tsunami Pump threads (comes with Tsunami Pump)	
W735	Female Quick Connect Perfect Union (for water-bed style valves)	
W736	• 3/4" Quick Connect sac threads (for use with W740 and W742)	
W737	• 3/4" Barbed End sac threads (for integrating multiple sacs)	
W738	1 1/8" Male Quick Connect with Barbed End (comes with Tsunami Pump)	
W739	Quick Connect Cap	
W740	• Flow-Rite 3/4" Straight Quick Connect (for use with W736)	
W741	• Flow-Rite 1 1/8" Straight Quick Connect (for use with W743)	
W742	• Flow-Rite 3/4" Elbow Quick Connect (for use with W736)	
W743	• 1 1/8" Quick Connect sac threads (for use with W741 and W746)	
W744	Pro X Series Check Valve System	
W745	3/4" Barbed Tsunami Pump	
W746	• Flow-Rite 1 1/8" Elbow Quick Connect (for use with W743)	
W747	Sac Valve Thread for Tsunami Pump (thread Tsunami Pump directly to sac)	
W748	• 1" Barbed to 1 1/8" Quick Connect	
W749	Air Release Valve (Turn to release air. For manually filling; not for venting automatic systems)	
W753	• 1" Barbed In-Line Check Valve	
W755	• 1 1/8" Barbed In-Line Check Valve	

NOTE: There are many possible combinations using our Quick Connect fittings. If you are trying to accomplish something and aren't sure how to best handle it, please contact us and we will be glad to help.

IMPORTANT: Use All-Purpose PVC Cement on the threads of the W733, W736, W737, W743, and W747 when screwing them into Fatsacs.